



- 1) Use 0.25" pads for IO
- 2) Add polyfuse
- 3) Add undervoltage FET to Lipp circuit
- 4) Add brown out monitor to uP
- 5) Omit PSAVE signal by always turning on H-bridge

Paper Computer Engine
Size: 35x50mm

Copyright Doug Commons 2013

Paper_Car_Engine

27/12/2013 9:12:41 AM

Sheet: 1/1